

(PRACTICAL) COMPUTATIONAL PHYSICS

Physics 551
Lecture 13

NOTATION

Extra Reading

Optional Exercise

Recommended

- This lecture slides for this course will attempt to use a uniform notation throughout. A normal paragraph looks like this.
- 👁 *Italicized paragraphs with pen bullets will indicate definitions, with the defined word or phrase shown in **SMALL-CAPS**.*
- ✎ Pencil bullets will indicate the introduction of **new notation**.
- 👉 Pointing hand bullets indicate important points that might otherwise be overlooked.

ANNOUNCEMENTS

ANNOUNCEMENTS

- This week a **new** VirtualBox virtual machine that uses **Microsoft Windows 7** as its operating system is required.
- The Virtual Machine image requires approximately **30 GB** of storage space.
- Instructions for obtaining it can be found on the Blackboard Learn website.

MICROSOFT WINDOWS ENVIRONMENT

THE DESKTOP AND SETTING UP



WINDOWS GIT SETUP

- Run the “Git Shell” utility using the Desktop shortcut.
- Invoke the following commands:

```
$ git config --global user.name "<your_github_username>"
```

```
$ git config --global user.email "<your_email_address>"
```

```
$ git clone https://github.com/hughdickinson/CompPhysL13Labview.git  
C:/Users/ComputationalPhysics/Documents/labview/lecture13
```

- Replace the **red** text with values that are appropriate for you.

DEMONSTRATION

Cloning the LabView Demonstration Material **in Windows**

LABVIEW

LABVIEW OVERVIEW

- 👁️ National Instruments **LabView** is an **INTEGRATED DEVELOPMENT ENVIRONMENT** (IDE) that is designed to simplify the development of hardware control and data acquisition interfaces.
- 👉 LabView provides a **graphical programming interface** and implements a **data flow** programming paradigm using a programming language called **G**.
- 👉 Program development entails definition of **connections** that **transfer data** between discrete **computational elements**.

LABVIEW OVERVIEW


- 👁️ *LabView programs are called **VIRTUAL INSTRUMENTS** (or **VIs**).*
- 👁️ *VIs can be used as **self-contained functional elements** within other VIs. In this case, they are referred to as **SUB-VIs**.*
- 👁️ *Communication of data **between** sub-VIs is possible if their definition includes appropriate **TERMINAL** elements.*
- 👉 *Hardware vendors often provide sets of **ready-to-use** VIs that interface with the instruments they sell.*

THE LABVIEW INTERFACE


- The **basic** LabView interface comprises **two main windows**.
 - ☞ The **FRONT PANEL** window provides a preview of the Graphical User Interface with which the **end-user** of the software will interact.
 - ☞ The **BLOCK DIAGRAM** window displays a graphical representation of the **G** program and provides an interactive interface to modify and develop its functionality.

THE FRONT PANEL

- ☞ The front panel is used to **position** and **customize** the UI elements of **your** program.
- Elements in the front panel are classified as **controls** or **indicators**.
- The front panel is **not** used to develop functional **G** code.







THE BLOCK DIAGRAM



- 👁 The block diagram displays the connections (or **WIRES**) between the different elements that comprise a LabView program.
- In addition to **control** and **indicator** elements, the block diagram also displays **functional** elements that perform mathematical computations or data manipulation.
- **Numerical constants** and **flow control structures** like **for-loops** can also be defined in the block diagram.

CRUCIAL INTERFACE ELEMENTS

- To test-execute a LabView VI while it is under development use the **Run** button ().
- ☞ If there are problems with your VI that prevent it from executing, the Run button will display a broken arrow (.
- To display the values of data flowing along wires in the block diagram use the **Highlight Execution** button (.
- Brief **contextual help** for any elements in the block diagram or front panel can be obtained using the **Context Help Button** (.


DEMONSTRATION

Very **Basic** Introduction to the **LabView Interface**

DATA FLOW MODEL

- The **G** language models computer programs as the **flow** of data along **wires** that connect functional **elements**.
- ➡ LabView is a **strongly typed** language.
- ➡ The **colour, width** and **patterning** of a wire identifies the **type** of data it carries.
- ***If no information is lost, the LabView interface will convert between numeric types. This is called **COERCION**.***
- ➡ All other type conversions **must** be **explicitly** specified in the block diagram.

EXAMPLES OF DATA TYPES



Floating Point Data

Integer Data

Red Connection Indicates **coercion**.

String Data

Explicit **conversion** between **string** and **floating point** data.

Thicker lines indicate array data.

FUNDAMENTAL NUMERIC TYPES

- LabView provides two **fundamental** numeric types
 - **Integral** types.
 - **Floating-point** types.
- Like C++, LabView can **represent** numerical data using different, **fixed** numbers of bytes.
- The type and representation associated with numerical **controls**, **indicators**, and **constants** can be selected from the front panel **and** the block diagram.

DEMONSTRATION

Working with **typed data** in LabView

ARRAYS

- ➡ In **G**, arrays are collections of data that have the **same type**.
- ➡ Array **elements** can be defined **statically** (i.e. at compile time), or generated **dynamically** using **functions**, **VIs** or **looping structures**.
- ➡ **G** supports the creation of **multidimensional** arrays.
- ➡ The **dimensionality** of array data that are transmitted along wires is indicated by their **width** in the block diagram.


ARRAYS

0D 1D 2D 3D 4D 5D

Floating Point

Integer


String



CLUSTERS

- 🔑 In **G**, **CLUSTERS** are collections of data that have **different types**.
- 👉 Like arrays, the **elements** of clusters can be defined **statically** (i.e. at compile time), or generated **dynamically** using **functions** or **VIs**.
- 👉 Clusters elements are stored **in order** and can therefore be retrieved according to their **positions** within the cluster.
- 👉 Cluster elements may also have a **unique** associated **identifiers**, which can also be used to retrieve their values.

CLUSTERS



- The **Unbundle** function retrieves cluster elements based upon their positions
- The **Unbundle By Name** function retrieves elements based on their identifiers.
- The **Bundle By Name** function can be used to modify cluster element values.
- The **Bundle** function can be used to **add new** elements to a cluster.

DEMONSTRATION

Working with **Arrays and Clusters** in LabView

SUB-DIAGRAMS


- Implementation of **conditional** or **looping** structures in a graphical programming language like **G** requires **isolation of subsets** of the block diagram.
- 👁️ *The isolated subsets are referred to as **SUB-DIAGRAMS**.*
- 👉 Sub-diagrams are defined by **enclosing** elements of the block diagram within a **graphical boundary**.
- 👉 Wires that **cross** the boundary of a sub-diagram must pass through a **terminal** as they do so.

CONDITIONAL STRUCTURES

- 👁️ **Conditional branching** in LabView is accomplished using **CASE STRUCTURES**.
- 👁️ Case structures comprise **several** sub-diagrams containing **different** assemblages of programmatic elements.
- 👁️ The sub-diagram that is executed is controlled by a **value** supplied to a **CASE-SELECTOR** terminal provided by the case structure.
- 👉 The **value** that is supplied **must** be **boolean** or **integral**.

CASE STRUCTURE EXAMPLE


Integral case-selector is valid **and**, *boolean* is **True**.



Integral case-selector

CASE STRUCTURE EXAMPLE


Integral case-selector is **invalid**, so **default** case executes.



Valid **integral** values

CASE STRUCTURE EXAMPLE

Boolean case-selector is **False**. String **not** modified.



Boolean case-selector

False **boolean** value

DEMONSTRATION

Working with **Case Structures** in LabView

FLOW CONTROL STRUCTURES

- The **G** language provides control structures including **for-loops** and **while-loops** that permit repeated execution of a subset of the elements that constitute a VI.
- ☞ In order to interact with **real-world** hardware systems LabView implements an **asynchronous** execution model.
- To handle asynchronicity, **G** also defines a number of **precisely timed, strictly sequential** or **event driven** control structures.
- ☞ **Independent** components of a VI execute in **parallel** if possible.

FOR-LOOPS


- For-loop structures repeatedly execute the sub-diagram elements that they enclose a **fixed** number of times.
- ☞ For-loop structures define one **external count** terminal that **may receive** the fixed number of loop iterations to perform.
- ☞ For-loop structures define one **internal iteration** terminal that **provides** the current iteration to the logic **within** the loop structure.

INDEXING TERMINALS

- 👁️ A for-loop structure will **automatically** iterate over **all** elements of an array if a wire carrying array-type data is connected to an **INDEXING TERMINAL** on the structure.
- 👉 An indexing **input** terminal is created **by default** whenever a wire carrying array-type data **enters** a **for-loop** structure.
- 👉 An indexing **output** terminal is created **by default** whenever a wire **exits** a **for-loop** structure.

FOR LOOP EXAMPLE


- **Explicit** specification of required **iteration multiplicity** entails connection of a wire carrying *integral* data to the **count** (**N**) terminal on the boundary of the **for-loop sub-diagram**.



☞ Indexing terminals appear **hollow**

FOR LOOP EXAMPLE

- Wires carrying **array-type** data **automatically** create indexing input terminals when they transit the sub-diagram **boundary of a for-loop**. In such cases, **explicit** specification of the iteration multiplicity is **not** required.



DEMONSTRATION


Working with **For-Loops** in LabView

WHILE-LOOPS

- While-loops repeatedly execute the elements of their associated sub-diagram **until** a **boolean** termination criterion is fulfilled.
- While loops provide two internal terminals:
 - ▶ The **conditional** terminal that **requires** a **boolean** input corresponding to the evaluated termination criterion.
 - ▶ The **iteration** terminal that **provides** the current iteration to the logic **within** the loop structure.

WHILE-LOOP EXAMPLE

Conditional terminal



☞ While loops do **not** automatically generate indexing terminals on their sub-diagram boundaries.

DEMONSTRATION


Working with **While-Loops** in LabView

SHIFT REGISTERS

- 🔑 ***SHIFT REGISTERS** are used to pass data from one loop iteration to the next.*
- **Terminals** on the boundaries of loop-structure sub-diagrams can be **converted** into shift registers using the LabView GUI.
- **Multiple** shift registers can be used to obtain data from **several** previous iterations.
- If a shift register could refer to a **non-existent** iteration, a **default** input value **must** be specified.

SHIFT REGISTER EXAMPLE

Output shift register passes data to subsequent iterations.



Input shift registers receive data from previous iterations.

DEMONSTRATION

Working with **Shift Registers** in LabView


BASIC LOOP TIMING

- LabView provides a **Timed Loop** structure that facilitates fine-grained **control** and **monitoring** of the execution duration of the associated sub-diagram.
- Coarse **limitation** of the iteration **rate** can be achieved by including the the LabView **Wait** function in the loop sub-diagram.
- The **Wait** function pauses execution of the loop sub-diagram for a specified number of **milliseconds** and subsequent iterations will not proceed unless that interval has expired.

BASIC LOOP TIMING EXAMPLE

Integral input to the **Wait** function specifies a 1000ms pause in execution.

Wait function pauses execution for a specified number of milliseconds




➡ Each iteration of the while-loop takes **at least** 1 second. Operations may require additional time to execute.

VARIABLES

- 👁️ ***VARIABLES in LabView** are used to transmit data between programmatic elements “wirelessly”.*
- Variables can transmit data between **elements** and **sub-diagrams** in the **same VI**, between **different VIs** and even between **different computers** across a network.
- 👉 Variables avoid the **explicit serial execution** of connected elements associated with the “wired” data flow model.
- 👉 Variables are used to enable transmission of data between sub-diagrams that should execute in **parallel**.

VARIABLES EXAMPLE

- The **values** displayed by **indicators** can be **defined** as variables.



DEMONSTRATION

Basic Loop Timing and **Working with Variables**

RECOMMENDED READING

Learn LabVIEW Online Video Tutorials

(<http://www.ni.com/academic/students/learn-labview/>)

LabVIEW Basics Online Reference

(<http://www.ni.com/getting-started/labview-basics/>)

LECTURE 13 HOMEWORK

- Review the ***Recommended Reading*** items listed on the previous slide.

Continue to refine your **final project proposal** and begin working on your **final project** once it is approved.